


## 安装外型尺寸



型号	尺寸 (mm)																							
	L1	L2	L3	H	D	E	M	m	a	b	n	A	B	C1	C2	C3	d	Q	h					
FR7-25X*L	127	74	45	25	75		M22x1.5	M18x1.5				90	70	53	45	39	φ9			10				
FR7-40X*L	158						M27x2																	
FR7-63X*L	185	93	60	33	95		M33x2														110	85	60	53
FR7-100X*L	245						M42x2																	
FR7-160X*L	322	108	80	40	φ110		M48x2														125	95	71 81	61
FR7-250X*F	422					φ50	60	68	125	95	71 81	61	39	φ13	60	15								
FR7-400X*F	467	135	100	55	φ130	φ60											90	50	140	110	90	68		
FR7-630X*F	494	175	118	70	φ160	φ90	120	70	M10	170	140	110	85	102	18									
FR7-850X*F	606															73								
FR7-1000X*F	786															102								